



THESE WIRES, IN THE ENGINE WIRING HARNESS, HAVE NO CONNECTION IN A NEGATIVE GROUND SYSTEM AND MUST BE LEFT UNCONNECTED. THESE WIRES ARE USED FOR THE NEGATIVE TERMINAL IN A FLOATING GROUND (TWO TERMINAL) SYSTEM.

THIS WIRE IS SUPPLIED ONLY WITH A NEGATIVE GROUND SYSTEM. DO NOT USE IN A FLOATING GROUND (TWO TERMINAL) SYSTEM.

I. ALL GAUGES ARE MANUFACTURED BY BEEDE.

REVISIONS		DRAFTER		CHECKER		APPROVAL	
REV	DESCRIPTION	DATE	INITIALS	DATE	INITIALS	DATE	INITIALS
00	110700-023 RELEASED						

THIS DOCUMENT (AND THE INFORMATION SHOWN THEREON) IS CONFIDENTIAL AND PROPRIETARY AND SHALL NOT BE DISCLOSED TO OTHERS IN ANY FORM OR BY ANY MEANS, OR USED FOR ANY PURPOSE WITHOUT WRITTEN CONSENT OF COMBATS INC.

DIMENSIONING AND TOLERANCING PER ASME Y14.5M-1994		ITEM NAME	
REF. ITEM NO.		SCHEMATIC, WIRING	
DRAWN BY		IDENTIFIER	
CHECKED BY		DIAGRAM DRAWING	
DESIGNED BY		PART NUMBER	
APPROVED BY		SCALE	
		NONE	
		5288175	
		1	

12V BEEDE INSTRUMENT PANEL (SECOND STATION)

12V BEEDE INSTRUMENT PANEL (MAIN STATION)

Y ADAPTER HARNESS (USED WITH DUAL STATION SYSTEM)

ENGINE WIRING